

Product data sheet

Rocker with lens and arrow symbols for KNX push-button 1-gang



Reference number

AL 101 KO5P D

1-gang rocker with lens and arrow symbols

for JUNG HOME push-button 1-gang, battery-powered, ref.-no.: Art.-Nr.: BT LS CD 1001
for KNX push-button 1-gang ref.-no.: LS CD 10711 ST, LS CD 10911 ST

Metal versions

Colour:
dark (aluminium lacquered)

Material:
aluminium lacquered