

Product data sheet

1-gang rocker with lens for switch and push-button with indicator light



Reference number

LC 990 KO5 32140

1-gang rocker with lens

Les Couleurs® Le Corbusier

for switch with indicator light ref.-no.: 502 KOU, 503 KOU, 506 KOU, 501-20 KOU,
502-20 KOU, 506-20 KOU

for push switch with indicator light ref.-no.: 502 KOTU, 506 KOTU

for push-button ref.-no.: 531 U, 533 U, 533-2 U, 534 U

Delivery time: please inquire for exact date

Spare part:

holder plate ref.-no.: CD 90 HP

Duroplastic lacquered
Colour:

ombre naturelle 31

Material:

duroplastic lacquered
