

Product data sheet

1-gang rocker with symbol "light"



Reference number

CD 590 L GB

1-gang rocker with symbol "light"

for switch ref.-no.: 501 U, 502 U, 503 U, 506 U, 507 U, 501-20 U, 506-20 U, 507-20 U

for push switch ref.-no.: 502 TU, 506 TU, 507 TU

for push-button ref.-no.: 531 U, 532 U, 533 U, 533-2 U

For illuminated inserts use rocker with lens ref.-no.: ..KO...

Spare part:

holder plate ref.-no.: CD 90 HP

for metal versions ref.-no.: CD 90 MHP

Metal versions (anodized aluminium)

Colour:

gold-bronze

Material:

anodized aluminium