

Product data sheet

2-gang rocker for switch and push-button, with lens



Reference number

SL 595 KO5 WW

2-gang rocker with lens

for switch ref.-no.: 505 U 5

for switch with indicator light ref.-no.: 505 KOU 5

for push-button ref.-no.: 535 U 5

Spare part:

holder plate ref.-no.: SL 95 HP

Push-switch inserts are recommended because the triggered rocker returns into original position.

Colour:

white